MICROFILER DISK FORMAT PROGRAM

This basic program will prepare a disk for use with **MicroFiler**™ for users of most DOS other than Atari 2.0S DOS.

To prepare this program for use:

1. Type in the program. Note: it is not necessary to type in line 1 through 9 (the REM statements).
2. SAVE the program to disk.

To use the program:

1. Load the program.
2. Remove the program disk and insert the disk to be used with **MicroFiler**. This can be blank, or a disk with data or programs you no longer want.
3. RUN the program.
4. You will be reminded that this program will format (erase) the disk, and asked if you have the correct disk in the drive. At this point, double check the disk, then type "Y" and RETURN if it is correct.
5. The disk will now format for use with **MicroFiler.**

```
1 REM ----------------------------
2 REM THIS PROGRAM IS DESIGNED TO
3 REM FORMAT DISKS TO BE USED WITH
4 REM MICROBITS PERIPHERAL PRODUCT'S
5 REM MICROFILER.  CAUTION!!  THIS
6 REM PROGRAM WILL FORMAT (ERASE ALL
7 REM DATA) THE DISK IN THE DRIVE
8 REM WHEN IT IS RUN!
9 REM ----------------------------
10 DIM A$(1),RTN$(5)
15 ? CHR$(125);CHR$(253)
20 ? "This program will FORMAT the disk in"
25 ? "the disk drive!!  DO YOU HAVE THE"
30 ? "CORRECT DISK IN THE DRIVE??"
35 ? "[Y/N]:";
40 INPUT A$
50 IF A$(1,1)<>"Y" THEN END
60 FOR I=1 TO 5:READ X:RTN$(I,I)=CHR$(X):NEXT I
70 DATA 32,83,228,104,96
80 POKE 769,1:POKE 770,33
90 POKE 772,0:POKE 773,6
100 A=USR(ADR(RTN$))
110 IF PEEK(771)<>1 OR PEEK(776)<>0 OR PEEK(777)<>0 THEN GOTO 80
120 POKE 770,82:POKE 778,104:POKE 779,1
130 A=USR(ADR(RTN$))
140 POKE 1539,195:POKE 1540,2:POKE 770,87
150 A=USR(ADR(RTN$))
160 ? "ALL DONE!";CHR$(253):END
```